


Procedure

1 Prepare the surface

Clean the surface with a pressure washer (1500PSI) and remove any dirt with *TexNov's Surface Preparer*. Seal any cracks with *TexNov's Crack Filler*.

2 Apply the coating

Apply two coats of *Pave-Tex* coating with a brush or a 10mm roller. Leave 24 hours between both layers.



- TexNov's surface preparer
- TexNov's crack filler
- Pave-Tex textured coating



