

PREPARATION AND APPLICATION PROCEDURE

AGGREGATE



PREPARATION

Procedure:

- Clean the surface with a pressure washer
- Note that if the concrete surface is dry, moisten before applying the **TexNov Surface Preparer**.
- **TexNov Surface Preparer** can be applied with a sprayer.
- Rinse with a pressure washer.
- Let the surface dry for 24 hours prior to applying the finish coating.

Note: Repair cracks if needed with **TexNov All-purpose Polymer**.

FINISH

Procedure:

- Apply 2 coats of **TexNov Acrylic Coating**.
Use a brush or roller with 10 mm bristles
(24 hours between applying each coat).
- Let the surface dry for 24 hours before applying the sealant.

Note: The appearance of your wall will be of uniform colour while retaining the rustic appearance of the aggregate.

SEALANT

Procedure:

- You can apply TexNov WRS-40 Sealant (waterproof sealant) to waterproof the surface.
(Optional) Use a brush or a roller with 10 mm bristles or sprayer
- Let the surface dry for 24 hours.

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer).
Let dry and add a coat of **WRS-40 Sealant** every 5 years or as needed.
This should enable you to keep your surface in good condition.

TexNov

839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3
www.texnov.com - info@texnov.com

1 877 316-6388

The application instructions and performance characteristics are based on information we believe to be reliable. They are offered to the best of our knowledge, but without guarantee, as conditions and methods of use of our products are beyond our control.