

PREPARATION AND APPLICATION PROCEDURE

ASBESTOS COVERING



PREPARATION

Procedure:

- Rinse well with a pressure washer.
- Clean with **TexNov Surface Preparer**.
- Let act for 15 minutes by keeping the surface wet.
- Rinse the surface well.
- Let the surface dry over a 48-hour period of good weather.

FINISH

After preparing the surface:**Procedure:**

- Apply two coats of **TexNov Acrylic Coating**. Use a brush or roller with 10 mm bristles (24 hours between each coat).
- Let the surface dry for 24 hours.

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer).

TexNov

839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3
www.texnov.com - info@texnov.com

1 877 316-6388

The application instructions and performance characteristics are based on information we believe to be reliable. They are offered to the best of our knowledge, but without guarantee, as conditions and methods of use of our products are beyond our control.