



# PREPARATION AND APPLICATION PROCEDURE

## ASBESTOS COVERING

PREPARATION	FINISH
<p><b>Procedure:</b></p> <ul style="list-style-type: none"><li>- Rinse well with a pressure washer.</li><li>- Clean with <b>TexNov Surface Preparer</b>.</li><li>- Let act for 15 minutes by keeping the surface wet.</li><li>- Rinse the surface well.</li><li>- Let the surface dry over a 48-hour period of good weather.</li></ul>	<p><b>After preparing the surface:</b></p> <p><b>Procedure:</b></p> <ul style="list-style-type: none"><li>- Apply two coats of <b>TexNov Acrylic Coating</b>. Use a brush or roller with 10 mm bristles (24 hours between each coat).</li><li>- Let the surface dry for 24 hours.</li></ul>

**Maintenance:** Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer).

