

## PREPARATION AND APPLICATION PROCEDURE

# BRICK AND TILE



### PREPARATION

**Procedure:**

- Rinse the surface thoroughly with a 2500 lb. pressure washer.
- Clean with **TexNov Surface Preparer**.
- Vigorously brush the surface and let sit for 15 minutes keeping the surface wet.
- Rinse the surface thoroughly with a pressure washer.
- Let the surface dry over a 48-hour period of good weather.

### FINISH

**Procedure:**

- In warm weather dilute with water (50 ml/liter) for ease of application.
- Apply two coats of **TexNov Acrylic Coating**. Use a brush or roller with 10 mm bristles (24 hours between each coat).
- Let the surface dry for 24 hours.

**Note:** **TexNov Acrylic Coating** can be applied to almost every type of brick or concrete roof tiles on condition the roof is in good shape.

### SEALANT

**Procedure:**

- You can apply **TexNov WRS-40** Sealant (waterproof sealant) to seal the surface. (Optional) Use a brush or a roller with 10 mm bristles or a sprayer.
- Let the surface dry for 24 hours.

**Maintenance:** *Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer).  
Let dry and add a coat of **WRS-40** Sealant every 5 years or as needed.  
This should enable you to keep your surface in good condition.*

**TexNov**

839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3  
[www.texnov.com](http://www.texnov.com) - [info@texnov.com](mailto:info@texnov.com)

**1 877 316-6388**

The application instructions and performance characteristics are based on information we believe to be reliable. They are offered to the best of our knowledge, but without guarantee, as conditions and methods of use of our products are beyond our control.