

PREPARATION AND APPLICATION PROCEDURE **CEDAR AND PINE (CLAPBOARD)**



PREPARATION

Procedure:

- Rinse the surface thoroughly with a pressure washer.
- Clean with **TexNov Surface preparer**.
- Vigorously brush the surface and let sit for 15 minutes keeping the surface wet.
- Rinse the surface thoroughly with a pressure washer.
- Let the surface dry over a 48-hour period of good weather.

SEALANT

After preparing the surface:

Procedure:

- In warm weather dilute with water (50 ml/liter) for ease of application.
- Onto the Masonite if the surface is cardboard, apply a coat of **TexNov Met-30** Sealant before applying the coating, otherwise rings will appear on the surface. Use a brush or roller with 10 mm bristles (24 hours between each coat).
- Let the surface dry for 24 hours.

FINISH

After preparing the surface and sealant (if necessary):

Procedure:

- Apply two coats of **TexNov Acrylic Coating**. Use a brush or roller with 10 mm bristles (24 hours between each coat).
- Let the surface dry for 24 hours.

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer).

TexNov

839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3
www.texnov.com - info@texnov.com

1 877 316-6388

The application instructions and performance characteristics are based on information we believe to be reliable. They are offered to the best of our knowledge, but without guarantee, as conditions and methods of use of our products are beyond our control.