PREPARATION AND APPLICATION PROCEDURE

FRESHLY POURED CONCRETE



PRÉPARATION

Ne s'applique pas.

ENDUIT DE FINITION

Ne s'applique pas.

SEALANT

For a freshly poured concrete floor done on the same day.

Procedure: Once concrete surface is dry (as soon as you can walk on it). Apply the **TexNov Met-30** Sealant as a curing agent. Use a brush or a roller with 10 mm bristles or a sprayer.



839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3 www.texnov.com - info@texnov.com

1 877 316-6388