



PREPARATION AND APPLICATION PROCEDURE

FRESHLY POURED CONCRETE

SEALANT

For a freshly poured concrete floor done on the same day.

Procedure: Once concrete surface is dry (as soon as you can walk on it). Apply the **TexNov Met-30** Sealant as a curing agent. Use a brush or a roller with 10 mm bristles or a sprayer.

