



PREPARATION AND APPLICATION PROCEDURE

GREEN WOOD

PREPARATION

It is not recommended to install TexNov Acrylic Coating on wood that has not been dried (or wood that is still green).