

PREPARATION AND APPLICATION PROCEDURE

GREEN WOOD



PRÉPARATION

It is not recommended to install TexNov Acrylic Coating on wood that has not been dried (or wood that is still green).

TexNov

839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3
www.texnov.com - info@texnov.com

1 877 316-6388

The application instructions and performance characteristics are based on information we believe to be reliable. They are offered to the best of our knowledge, but without guarantee, as conditions and methods of use of our products are beyond our control.