

PREPARATION AND APPLICATION PROCEDURE

PAVING STONES



PREPARATION

Procedure:

- Rinse the surface with a 3500 lb. pressure washer with rotating nozzle.
- Clean with **TexNov Surface Preparer**.
- Vigorously brush the surface and allow 15 minutes for it to act keeping the surface wet.
- Rinse the surface thoroughly with a pressure washer.
- Let the surface dry over a period of 48 hours of good weather before applying the sealant.

SEALANT

After preparing the surface:

Procedure:

- Directly apply 2 coats of **Met-HD** Sealant (48 hours between each coat) onto the surface. Use a brush or roller with 10 mm bristles.
- Let the surface dry for 24 hours.

Maintenance: *Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer).
Let dry and add a coat of **Met-HD** Sealant every 3 years or as needed.
This should enable you to keep your surface in good condition.*

TexNov

839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3
www.texnov.com - info@texnov.com

1 877 316-6388

The application instructions and performance characteristics are based on information we believe to be reliable. They are offered to the best of our knowledge, but without guarantee, as conditions and methods of use of our products are beyond our control.