



PREPARATION AND APPLICATION PROCEDURE

STAMPED CONCRETE

PREPARATION	FINISH	SEALANT
<p>Procedure:</p> <ul style="list-style-type: none"> - If your concrete is covered with paint or sealer, remove the paint with a sandblaster, diamond grinder, or other suitable means. - Clean the surface with a 2500-pound water pressure washer with rotating jet, gasoline engine. (Available in tool rental centers.) - Dilute the TexNov Surface Cleaner. - If the concrete surface is dry, wet the surface before applying TexNov Surface Cleaner. With a sprayer let stand 10 to 15 minutes, brush as needed - Rinse thoroughly with a pressure washer. - Let the surface dry for 48 hours of good weather. - Repair cracks or level the surface with TexNov All Purpose Polymer. - Allow the surface to dry for 24 to 48 hours in good weather. 	<p>- Not recommended</p>	<p>Procedure:</p> <ul style="list-style-type: none"> - Apply 2 coats of TexNov Met-30 Sealant (24h between each coat). - Let the surface dry for 24 hours before stepping on it. <p>Procedure for SUPERIOR protection:</p> <ul style="list-style-type: none"> - Apply 2 coats of Sealant Met-30 (24h between each layer) or TexNov Met-HD (48h between each layer). - Let the surface dry for 24 hours or 48 hours of good weather before stepping on it. <p>Important: For the passage and / or vehicle parking a wall of 30 days will be necessary.</p>

Maintenance: Clean the surface with the **TexNov Surface Preparer** (6water / 1 Preparer). Let dry and add a coat of Sealant **Met-30** or **Met-HD** every 3 years or as needed; This should enable you to keep your surface in good condition.

