

## PREPARATION AND APPLICATION PROCEDURE

# STAMPED CONCRETE



### PREPARATION

**Procedure:**

- If your concrete is covered with paint or sealer, remove the paint with a sandblaster, diamond grinder, or other suitable means.
- Clean the surface with a 2500-pound water pressure washer with rotating jet, gasoline engine. (Available in tool rental centers.)
- Dilute the **TexNov Surface Cleaner**.
- If the concrete surface is dry, wet the surface before applying **TexNov Surface Cleaner**. With a sprayer let stand 10 to 15 minutes, brush as needed
- Rinse thoroughly with a pressure washer.
- Let the surface dry for 48 hours of good weather.
- Repair cracks or level the surface with **TexNov All Purpose Polymer**.
- Allow the surface to dry for 24 to 48 hours in good weather.

### FINISH

- Not recommended

### SEALANT

**Procedure:**

- Apply 2 coats of **TexNov Met-30** Sealant (24h between each coat).
- Let the surface dry for 24 hours before stepping on it.

Procedure for **SUPERIOR** protection:

- Apply 2 coats of Sealant **Met-30** (24h between each layer) or **TexNov Met-HD** (48h between each layer).
- Let the surface dry for 24 hours or 48 hours of good weather before stepping on it.

**Important:** For the passage and / or vehicle parking a wall of 30 days will be necessary.

**Maintenance:** Clean the surface with the **TexNov Surface Preparer** (6water / 1 Preparer). Let dry and add a coat of Sealant **Met-30** or **Met-HD** every 3 years or as needed; This should enable you to keep your surface in good condition.

**TexNov**

839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3  
[www.texnov.com](http://www.texnov.com) - [info@texnov.com](mailto:info@texnov.com)

**1 877 316-6388**

The application instructions and performance characteristics are based on information we believe to be reliable. They are offered to the best of our knowledge, but without guarantee, as conditions and methods of use of our products are beyond our control.