


PREPARATION AND APPLICATION PROCEDURE

ACRYLIC COATINGS



PREPARATION

Procedure:

- Thoroughly rinse the surface with a pressure washer.
- Apply **TexNov Surface Preparer**.
- Vigorously brush the surface and allow 15 minutes for it to act.
- Rinse the surface thoroughly with a pressure washer.
- Let the surface dry over a period of 48 hours of good weather before applying the finish coat.

FINISH

After preparing the surface:

Procedure:

- Apply two coats of **TexNov Acrylic Coating**. Use a brush or roller with 10 mm bristles (24 hours between each coat).
- Let the surface dry for 24 hours.

SEALANT

After preparing the surface and applying the coating:

Procedure:

- Apply 2 coats of **TexNov WRS-40** Sealant (waterproof sealant) to waterproof the surface. Use a brush or roller with 10 mm bristles or a sprayer (24 hours between each coat). (Optional)
- Let the surface dry for 24 hours.

Maintenance: Clean the surface with **TexNov Surface Preparer** (3 water / 1 Preparer).
Let dry and add a coat of **WRS-40** Sealant every 5 years or as needed.
This should enable you to keep your surface in good condition.

TexNov

839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3

www.texnov.com - info@texnov.com

1 877 316-6388

The application instructions and performance characteristics are based on information we believe to be reliable. They are offered to the best of our knowledge, but without guarantee, as conditions and methods of use of our products are beyond our control.