



PREPARATION AND APPLICATION PROCEDURE

FIBERGLASS

PREPARATION	FINISH	SEALANT
<p>Procedure:</p> <ul style="list-style-type: none"> - On fiberglass, sandblast with a roller sandblaster (with 40 grit sandpaper), and wash with acetone. Then wipe the surface with a cloth soaked with acetone and allow to dry. - Allow the surface to dry completely. <p>Note: If the fiberglass is cracked and water has seeped under the resin, the useful life of your floor is over.</p>	<p>Procedure:</p> <ul style="list-style-type: none"> - In warm weather dilute with water (50 ml/liter) for ease of application. - <u>The temperature of the surface should not exceed 30 ° C at the application.</u> - Apply two coats of TexNov Acrylic Coating. Use a brush or roller with 10 mm bristles (24 hours between each coat). - Let the surface dry for 24 hours. 	<p>Procedure:</p> <ul style="list-style-type: none"> - Apply 2 coats of TexNov Met-30 Sealant. Use a brush or roller with 10 mm bristles (24 hours between each layer). - Let the surface dry for 24 hours.

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer). Let dry and add a coat of **Met-30 Sealant** every 3 years or as needed. This should enable you to keep your surface in good condition.

