PREPARATION AND APPLICATION PROCEDURE

PLYWOOD



PREPARATION

Procedure:

- Clean with Texnov Surface Preparer.
- Let the surface dry for 48 hours.
- Caulk your joints with elastomeric polyurethane caulking (e.g.: Adbond 009, Sonneborn NP1 caulking or equivalent) taking care to caulk only the joints.
- Sand well to roughen the surface (with 60 grain sandpaper).

SEALANT

Procedure:

- Apply 2 coats of *Met-30* Sealer to prevent resin and glue from passing through the coating and dark circles on the surface. Use brush or roller with 10 mm bristles (24h between each layer).
- Allow the surface to dry for 24 hours.

FINISH

Procedure:

- In warm weather dilute with water (50 ml/liter) for ease of application.
- You can fill the screw heads with **TexNov Acrylic Coating** (screws should be rust proof: zinc, ceramic).
- Apply 2 coats of *TexNov Acrylic Coating*. Use a brush or roller with 10 mm bristles (24 hours between applying each coat of sealant).
- Let the surface dry for a 24-hour period before applying the sealant.

Note: TexNov Acrylic Coating will not hide all defects due to an unevenly installed substrate.

SEALANT

Procedure:

- Apply 2 coats of *Met-30* Sealant. Use a brush or roller with 10 mm bristles (24 hours between each coat).
- Let the surface dry for 24 hours.

Note: All wood surfaces located less than 60" from the ground or poorly ventilated should ideally be sealed on all sides with *Met-30* Sealant. This will prevent premature deterioration of the wood due to the migration of moisture from the ground to the sky.

Maintenance: Clean the surface with TexNov Surface Preparer (6 water / 1 Preparer). Let dry and add a coat of Met-30 Sealant every 3 years or as needed. This should enable you to keep your surface in good condition.



839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3 www.texnov.com - info@texnov.com

1 877 316-6388