

## PREPARATION AND APPLICATION PROCEDURE

# ROUGHCAST



### PREPARATION

#### Procedure:

- If your foundation is covered with old plaster which is ungluing or any other unstable materials, remove them by using the appropriate tools.
- Clean the surface with a rotary jet, 2500 lb. pressure washer, gasoline motor. (Available at tool rental centers.) This will also allow you to verify the adhesion of the plaster to the substrate.
- In a clean container, dilute the **TexNov Concrete Conditioner** reduced with 50% water.
- The concrete surface must be wet when applying **TexNov Concrete Conditioner**.
- Vigorously brush the surface with the **TexNov Concrete Conditioner**.
- Rinse thoroughly with the pressure washer.
- Let the surface dry over a period of 48 hours of good weather before applying the finish coating.

**Note:** All defects, metal rods, etc... must be repaired with **TexNov All-purpose Polymer** or **TexNov 200** before applying the coloured **TexNov Acrylic Coating** for a smooth result.

### FINISH

#### Procedure:

- Apply two coats of **TexNov Acrylic Coating**.  
Use a brush or roller with 10 mm bristles  
(24 hours between each coat).
- Let the surface dry for 24 hours.

**Maintenance:** Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer).

**TexNov**

839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3  
[www.texnov.com](http://www.texnov.com) - [info@texnov.com](mailto:info@texnov.com)

**1 877 316-6388**

The application instructions and performance characteristics are based on information we believe to be reliable. They are offered to the best of our knowledge, but without guarantee, as conditions and methods of use of our products are beyond our control.