# PREPARATION AND APPLICATION PROCEDURE

# SOFTWOOD



## **PREPARATION**

#### **Procedure:**

- Thoroughly rinse the surface with a 2000-pound pressure washer.
- Clean with *Texnov Surface Cleaner* undiluted or diluted 1:1.
- Brush the surface and leave for 15 to 30 minutes.
- Rinse the surface thoroughly with a pressure washer.
- Make a good sanding to make the surface rough with sand paper 60 grit.
- Let the surface dry for 48 hours of good weather.

# **SEALANT**

#### **Procedure:**

- TexNov Met-30 sealant should be applied over the entire surface of some softwood substrates prior to the installation of the finish coat. Example: Pine, Cedar, Spruce
- Allow the surface to dry for 24 hours.

# **FINISH**

#### **Procedure:**

- In warm weather dilute with water (50 ml / liter) for ease of application.
- You can fill the screw heads with **TexNov Acrylic Coating**. (screws must be rustproof: zinc, ceramic).
- Apply 2 coats of **TexNov Acrylic Coating**. Use brush or roller with 10 mm bristles. (24h between each layer).
- Allow the surface to dry for 24 hours.

**Note:** *TexNov Acrylic Coating* will not hide any defects due to unevenly installed substrate.

## **SEALANT**

#### Procedure:

- Apply 2 coats of *Met-30* Sealant. Use a brush or roller with 10 mm bristles (24 hours between each coat).
- Let the surface dry for a 24-period of good weather.

**Note:** All wood surfaces located less than 60" from the ground or poorly ventilated should ideally be sealed on all sides with *Met-30* Sealant. This will prevent premature deterioration of the wood due to the migration of moisture from the ground to the sky.

Maintenance: Clean the surface with TexNov Surface Preparer (6 water / 1 Preparer). Let dry and add a coat of Met-30 Sealant every 3 years or as needed. This should enable you to keep your surface in good condition.



839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3 www.texnov.com - info@texnov.com

1 877 316-6388