



PREPARATION AND APPLICATION PROCEDURE

STUCCO

PREPARATION	FINISH	SEALANT
<p>Procedure:</p> <ul style="list-style-type: none"> - Clean the surface with a 1000 lb. pressure washer. - In a clean container, dilute the TexNov Surface Preparer reduced with 50% water. - The concrete surface must be wet when applying TexNov Surface Preparer. - Rinse the surface thoroughly with a pressure washer. - Let the surface dry over a period of 48 hours of good weather. 	<p>After preparing the surface:</p> <p>Procedure:</p> <ul style="list-style-type: none"> - Apply two coats of TexNov Acrylic Coating (24 hours between each coat). If the stucco is rough, use a brush or roller with 20 mm bristles. - Let the surface dry over a period of 24 hours of good weather. 	<p>After preparing the surface and applying the coating:</p> <p>Procedure:</p> <ul style="list-style-type: none"> - You can apply TexNov WRS-40 Sealant (waterproof sealant) to seal the surface. (Optional). Use a brush or a roller with 10 mm bristles or a sprayer. - Let the surface dry for 24 hours. <p>Note: All defects must be repaired with TexNov All-purpose Polymer or TexNov 200 before applying coloured TexNov Acrylic Coating for a uniform result.</p>

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer). Let dry and add a coat of **WRS-40** Sealant every 5 years or as needed. This should enable you to keep your surface in good condition.

