

PREPARATION AND APPLICATION PROCEDURE

STUCCO



PREPARATION

Procedure:

- Clean the surface with a 1000 lb. pressure washer.
- In a clean container, dilute the **TexNov Surface Preparer** reduced with 50% water.
- The concrete surface must be wet when applying **TexNov Surface Preparer**.
- Rinse the surface thoroughly with a pressure washer.
- Let the surface dry over a period of 48 hours of good weather.

FINISH

After preparing the surface:**Procedure:**

- Apply two coats of **TexNov Acrylic Coating** (24 hours between each coat). If the stucco is rough, use a brush or roller with 20 mm bristles.
- Let the surface dry over a period of 24 hours of good weather.

SEALANT

After preparing the surface and applying the coating:**Procedure:**

- You can apply **TexNov WRS-40** Sealant (waterproof sealant) to seal the surface. (Optional). Use a brush or a roller with 10 mm bristles or a sprayer.
- Let the surface dry for 24 hours.

Note: All defects must be repaired with **TexNov All-purpose Polymer** or **TexNov 200** before applying coloured **TexNov Acrylic Coating** for a uniform result.

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer).
Let dry and add a coat of **WRS-40** Sealant every 5 years or as needed.
This should enable you to keep your surface in good condition.

839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3
www.texnov.com - info@texnov.com

1 877 316-6388

The application instructions and performance characteristics are based on information we believe to be reliable. They are offered to the best of our knowledge, but without guarantee, as conditions and methods of use of our products are beyond our control.